

Insert the leaves into the leaf base from top to down. Note that the number on the leaf should corresponds to the number on the base. Number marked from #36 to #1.Pls note #36 should be corresponded to #36 hole,35-35 ...1-1. Then fixed by a M6 screw at the overlap and connect the power cord to the leaves by male female connector. Tighten all the waterproof nuts.

Connect the power supply and power cable to the base by male female connector and tighten the waterproof nuts.